

## **TUBE FUNCTION AND LOCATION CHART**

### **PITTBULL CLASSIC HEAD**

**MODEL NUMBER ON CHASSIS IS G-100-CL  
BUT IS NOT THE SAME AS THE HUNDRED/CL**

Each 12AX7 has two sections/functions. Section A is shown first, Section B is second.  
Factory recommended tubes are listed under each location. Numbering sequence is right to left looking at back of amp starting with the row closest to front panel of amp.

V1 (shielded tube)      Input Gain Stage 1 and signal splitter for all 3 channels  
12AX7WB Sovtek

V2                              Gain Stage 2 for Lead channel.  
12AX7 China              Gain Stage 3 for Lead and Rhythm channels.

V3                              Gain Stage 4 for Lead channel.  
12AX7 China              Tone Control Driver for Lead and Rhythm channels.

V4                              Gain Stage 2 for Clean channel.  
12AX7 China              Gain Stage 2 for Rhythm channel.

V5                              Phase Inverter  
12AX7 China

V6                              Voltage Amp/Driver  
12AU7 China

V7-10                        Power Tubes.  
EL34 Svetlana

### **IMPORTANT NOTE**

**PHASE INVERTER V5 AND VOLTAGE AMPLIFIER TUBE V6 ARE  
NOT INTERCHANGEABLE WITH OTHER TYPES.**