



1201S. FLOWER STREET  
BURBANK, CA 91502  
PH (818) 846-4000 FAX (818) 846-4040

### **PITTBULL SERIES FUNCTIONS**

#### **FORTY- FIVE 2X10 & 2X12 COMBO, FORTY- FIVE HEAD**

##### **FRONT PANEL, LEFT TO RIGHT**

1. INPUT HIGH- High sensitivity input (also has a brighter tone)
2. INPUT LOW- Low sensitivity input (also has a slightly darker tone)
3. GAIN- Amount of overdrive. Initial set-up: 2 O'clock
4. DRIVE- Toggles between Drive and Clean channel
5. VOLUME- Pre FX loop. Initial set-up: 10 O'clock
6. BOOST- Switches from low gain (clean to slightly dirty) to medium gain (crunch to medium overdrive)
7. TREBLE- Initial set-up: 2 O'clock
8. EDGE- Frequency dependent gain boost; gain increases as you play up the neck.
9. MIDDLE- Initial set-up: 10 O'clock
10. SHIFT- Shifts Treble, Middle, and Bass shelving down
11. BASS- Initial set-up: 12 O'clock
12. VOLUME- Gain and volume for Clean channel, pre FX loop. Initial set-up: 9 O'clock
13. BOOST- Gain boost for Clean channel
14. TREBLE- Initial set-up: 2 O'clock
15. BRIGHT- High frequency boost ( becomes less active as Volume increases)
16. MIDDLE- Initial set-up: 10 O'clock
17. SHIFT- Low midrange boost between Middle and Bass frequencies
18. BASS- Initial set-up: 12 O'clock
19. REVERB- Initial set-up: 8 O'clock
20. PRESENCE- Initial set-up: 12 O'clock
21. STANDBY- 1=operate , 0= standby
22. MAINS- Lovely emerald green, don't you think?

## **PITTBULL FUNCTIONS**

### **FORTY- FIVE 2X10 & 2X12 COMBO, FORTY- FIVE HEAD**

#### **REAR PANEL, RIGHT TO LEFT**

1. EFFECTS MIX/LEVEL- Initial set-up: 5 O'clock
2. EFFECTS SEND- Send level set by preamp volumes
3. EFFECTS LOOP LEVEL- Sets overall level of loop (Out = 0dB, In = -10,dB)
4. EFFECTS SERIES/PARALLEL SWITCH- Sets loop for series or parallel operation
5. EFFECTS RETURN- Overall level adjusted by Hi/Low switch, then feeds to power amp
6. FOOTSWITCH JACK- 6Pin Din Connector
7. LINE OUT jack- Power amp line out
8. SPEAKER OUTPUT- Parallel wired
9. IMPEDENCE SELECT- 4,8,16 ohm
10. CLASS A/CLASS AB SWITCH- Sets operation of power tube to Class A or Class AB mode.
11. DC FUSE- Power supply fuse. ½ Amp Fast Acting
12. MAINS FUSE- AC line fuse. 3A Slo-Blo (USA), 3.5A Slo-Blo (Japan), T1.6A Time Delay Fuse (Europe).
13. GROUND SWITCH- 4,8,16 ohm. US and Japan only. Normally set to "0" position unless filly grounded outlet in not available. Set for minimum hum.